SCFA – Training Bulletin 22-08 Oil Burner Emergencies

Response may be due to a malfunctioning oil burner

Puff Back or Delayed Ignition – building may be filled with smoke; a fire may still be burning in firebox. Use dry chemical extinguisher or foam, water may cause damage and injuries to firefighters

Blocked or Dislodged Flue Pipe – building filled with smoke and high levels of CO. Verify levels with 2 CO meters.

Check for fire extension and account for all occupants. Check all floors for anyone who may be overcome.





Fire Department Actions

- Emergency Shut Off Switch is used to <u>de-energize unit</u>
- <u>Ventilate</u> area if needed
- <u>Stretch a hose line</u>
- Shut Off fuel supply
- <u>Check for fire extension</u> around and above unit. CO may be present on all floors
- Have <u>occupant call for service</u> company & may need to relocate, due to no heat in building.
 - SCBA to be worn Visit our website <u>www.scfa-li.org</u>